

2

BATTERY

LATCH RELAY

1

ത

LEFT HEADLT (CHEROKEE)

LT GRN WHT

LT GRN

BLK

<u>ع</u>

DK BLU

OK BLU

L

ł


- LEFT PARK LT

IR/HAZ SW

LT GRN D5 LT GRN BEAM

WAGONEER

DK BLU LEFT MARKER LT



1

STARTE

STARTER RELAY

RED FUS LINK RED FUS LINK

FUS LINK

ž

N.

GRN FUS LINK

(4.0 L)

GRN FUS LINK

3

GRM

GRN GLOW PLUG

REC

RED

BLU) FUS LINK

DK GR

I

મ**4.0**દ્ય

GRN

2(2.51)

BIKTO

(A/T)

RED

RENG COMPT LIGHT

GRN-T ECU PIN C3

4

(M/T)

ECU PIN #29

H 2 DK GRN IGN

ALTERNATOR

B


С

D

E

F

95643



2



